

SL008 Gold Pulse Facial Massager Operating manual



Introduction

Prospera's Gold Pulse Facial Massager is your one-way ticket to beautiful skin. This elegant and effective product is made from superior quality material to tone your complexion, reduce any wrinkles, and tighten the skin. It increases skin metabolism through high frequency stimulation and improved blood circulation, resulting in an instant face lift. Daily use of the Gold massager allows your face and skin to look healthier and younger.

Content

CONTENTS

Safety Warnings	.2
Product Illustration	.2
Operating the Product	.3
Consumer Warranty	.4
Product Specifications	.4
Varranty Card	5


Safety Warnings

Consult your doctor prior to using the product if you have heart, skin and/or other health-related issues


- 1. This product is intended for adult use only.
- 2. Do not let babies and children play with the product.
- 3. Do not use the product on an infant.
- 4. If you experience discomfort, stop using the product immediately.
- 5. Do not wash the unit using organic solvent such as thinner to prevent damage

Product Illustration

Product Structure



How to Use It



2

Operating the Product

Insert one AA battery in the battery chamber, and screw back the gold massage bar.



Wash your face, and follow with a small amount of facial serum or moisturizer.

Step 2

Step 1

Press button once, power is turned on and switched into the first vibration mode. Roll the gold bar in the direction of the arrows illustrated in the above diagram. Repeat each motion 10 times per area.

You may choose stronger intensity and/or other various modes by pressing the button, total 7 of them, as your daily routine.

Step 3

Roll the gold bar on both the front and back of your neck in an upward motion. Repeat 10 times for each area. You can use this same technique on other parts of the body, such as the chest, hands and arms, to improve the complexion of the skin in these areas.

You may feel a warming sensation (activation) as vibration massage generated by the product tighten up skin and improve blood circulation.

Recommend usage: 5-7 times per week

To order a new health and beauty product, please visit www.prosperacorp.com.

Use coupon code: PROS\$5 for \$5 off any product above \$30.

Consumer Warranty

Prospera offers a 90-day standard warranty on massage products. Labor and parts are included during the warranty period. Please provide the model number and dated proof of purchase (sales receipt) when contacting Prospera for warranty service

1

Non-warranty service is provided on a "per incident" basis. The consumer will verify that the product has failed and provide information for servicing the unit. All applicable repairs, parts, shipping, handling, local tax and "per incident" fees will be charged for non-warranty repairs and support calls.

Product Specifications

- · Features: smooth skin, face lift, anti wrinkles, improve circulation
- 7 auto vibration modes, max 6500rpm
- · Areas: face, neck, hands, and other soft parts of the body
- · Light weight, travel size, waterproof
- Material: Silica gel, ABS, PC
- Button power control with cool blue LED light
- Product Size: 5.28"x1.38"x1.18" • Weight: 2.1 oz (without battery)
- Rated Voltage: 1*AA, 1.5V
- Rated current:<= 400 mA Battery: 1 AA Alkaline battery
- Standard: GB4706.1-2005, GB4706.10-2008
- UPC 860000627573

Warranty Card



Warranty Registration Form
Product Name:
Product Model:

Date of Purchase: __ Retailer: First Name:

Last Name: ___ Address: ___ City:_____State:___ Phone: ___ __Email: ___

Please mail to:

Signature and date:

Prospera Corporation 392 West Larch Rd Suite 31 Tracy, CA 95304-1644 Tel:(925)292-5978 Email: sales@prosperacorp.com

3

4

5



DL008 Hot Mist Nano Facial Steamer - Operation Manual -

Thank you for purchasing this DL008 Hot Mist Nano Facial Steamer. In order to use this product correctly, please read this manual before use; and keep this manual in a safe place.

The product pictures, features and descriptions shown in this manual are for reference only. The user will use the actual product as your final default as the company keeps improving products.Referenced data comes from the company's laboratory.

Safety Precautions

Be sure to read the safety precautions before use. Please use this product correctly according to the content and recommendations of the manual.

Danger

Related content:Incorrect actions can lead to personal injury

Related content Incorrect operation can result Acaution in personal safety or property damage

○ Danger

- Do not insert objects into the nozzle or block the nozzle to avoid injury due to excessive steam pressure.
- Place the appliance on a flat and solid surface. It is forbidden to hold the DL008 and use it in your hands.
- Do not use this product near a water bath, washbasin or other damp areas
- If the power cord is damaged, it must be replaced by a professional from the manufacturer, its service department to avoid a hazardous consequence
- · Because it will spray hot water vapor, please use the appliance carefully.
- Unplug the power cord when filling and cleaning.
- Do not use if you feel dizzy, heat may cause burns.

 The appliance should be cleaned after use to avoid accumulation of dirt, grease and other residue.

- If you feel pain or abnormal, stop using it immediately.
- Unplug the power cord after using the product. Otherwise it may cause accidents or even personal injury.
- Do not disassemble or repair this product yourself. About repairs, please contact warranty or service. Otherwise, it may cause personal injury due to abnormal operation.
- Please dispose of this product properly, please keep out. of reach of children, and avoid accidents caused by child suffocation. Do not rinse to the device directly under water.
- . Do not use this appliance near flammable or explosive materials (alcohol, benzine, nail remover, spray, etc.), as
- This product may not be used by persons who are physically impaired, or mentally disabled, or lack of operation experience and knowledge, users are responsible for their safety, otherwise they need to be supervised.

these may result in fire or explosion.

- Do not tilt, shake or move the product during or within 5 minutes of use, otherwise hot water may be spilled or steam may be ejected from the nozzle, resulting in burns.
- . Before cleaning and maintenance, remove the power plug and allow the appliance to cool before proceeding.
- Please use distilled or purified water.
- Do not add any substances (such as essential oils, milk,etc) in the water. Unclean water can cause device malfunctions In severe cases, water vapor may be sprayed to cause burns
- If the water tank does not have water, or device stops spraying, it is forbidden to immediately pull out the water tank and add water to prevent spraying hot water causing burns. You must turn off the power first, and wait 5 minutes
- . The following people should not use: -Women during pregnancy or menstrual period;
- --People with allergies, those with skin diseases, dermatitis
- --People with skin damage, wetness, swelling, etc.
- --People had recent surgery and is recovering. --Particularly sensitive skin.
- --Children

Part Identidfication



Preparation before use

When you open the package for the first time, you may find residual water in the device. This is the water left over during factory's aging test. It is not a quality problem and can be used with confidence.

[Place]

Place the device on a flat. sturdy table.

[Add water]

Pull up the water tank, unscrew the tank cap, and pour water into the tank Then tighten the tank cover and load the tank into the device.

[Water quality requirements]

This product can only be used with distilled or purified water. Tap water, mineral water, geothermal water, acid water, and ionized alkaline water cannot be used because they contain high minerals.

[Spray time]

- A box of water can be sprayed for about 15 minutes.
- Excessive use will open the pores, it is recommended to use no more than two times a day.
- After steam care, basic skin care hydration (such as masking) is required, otherwise it will easily lead to dry skin.

How to Use

[1.Power supply]

Plug the power plug into a household power socket and power on. The power supply must meet the p requirements (110V~60Hz).

[2.Power on]

Press the power button to turn on the power. the power indicator light is on: The device began to work, and a bright light could be seen at the nozzle.

[3.Spray] After about 40 seconds, steam was sprayed at the nozzle.
Some hot water droplets may drip out

during the spraying process.

Therefore, in order to use safety, it is necessary to ensure that the distance from the nozzle to the human body is greater than 20 cm.

[4 Power off]

Press the power button to turn off the power and unplug the power cord.

If there is a break in the spray during use, it means that the water in the tank will be used up, please turn off the device.

4

Every time after use, be sure to pour residual water out of tank.Otherwise,it may cause odor after storage for a long

- 1. After use turn off the device unplug the power cord and wait for the device to cool for at least 5 minutes 2. Pull out the water tank, unscrew the water tank cov
- 3.Hold the DL008 with both hands, tilt it, and pour water inside the device from the drain. (You can tap the body by hand to shake the device during the pouring process
- which helps to pour out the water more thoroughly.) 4. Wipe the water off the body with a dry cloth or cotton pad.
- 5. Place the cleaned water tank back and store the device. Cleaning and maintenance
- 1.Before cleaning, turn off the DL008 and unplug the power. 2.It is recommended to wipe the power plug with a dry cloth once a month to prevent poor contact.
- 3.If the sealing film of the water-filled cover is misaligned, use your index finger against the ejector pin at the center of the water-filling cover and use your fingers to rotate the film to match the water-filling cap.
- 4 Protect the product from moisture accumulation
- 5.Do not use sharp or corrosive, volatile thinner cleaners. 6.It can be cleaned with a soft damp cloth and wiped with a soft, dry cloth.

After-sales

- 1. This appliance is intended for personal use only and is not suitable for commercial use.
- 2.We offer a 90 day warranty on the product, upon transaction date.
- 3. During the warranty period, labor and parts are covered. Please see details in warranty.

- 4.To apply for a warranty, the warranty card and (purchase receipts)shall be sent back to prospera service departmen
- 5. The company does not guarantee the following conditions Damage caused by improper use, such as using the wrong power supply, inserting the product into an improper, socket man-made damage etc.
- it has little effect on the function of the product. Product problems caused by other uses, or improper handling or non-professional repairs or the use of accessories other than the company
- -Consumables or bonus accessories.
 -Damage caused by force majeure factors (such as lightning, earthquakes, fires, floods, etc.). After-sales service does not include damage caused by the above reasons.

Environmental Protection

The symbol on this product or in the instruction manual or on the packaging indicates that this product cannot be disposed of as general household waste at the end Please consult your local government for recycling

according to the classification of waste

Specification

Product Name: Hot Mist Nano Facial Steamer Model: DL008

Voltage: AC 110-120V Rated Frequency:60Hz Power: 280W WaterTank: 3.52oz Net Weight: 1.93lb GrossWeight: 2.70lb

Product Dimensions: 6.56x6.1x7.0 inches Packing Dimensions: 8.7x7.2x8.35 inches Packing list: 1* main unit, 1* operation manual, 1*desiccant.

In lieu of continuous improvement of products the actual goods are subject to each production and shipment.

6

Consumer Limited Manufacturer's Warranty

Prospera warrants the Covered Product to be free of all defects in material and workmanship for 90 days from date of purchase. This warranty extends to the original buyer (only or and each successive buyer within the warranty period). Labor and parts are included during warranty period. Consumers are required to provide model number and dated proof of purchase (sales receipt) when contacting Prospera for the warranty service. This warranty is valid for all US customers in the 48 continents states, and two non continental states: Alaska and Hawaii.

Within the period of this warranty, Prospera will repair or replace, free of charge, any part proving defective in material and workmanship. All warranty repairs and service must be performed by Prospera authorized technician and service facility. All expenses related to replacing or repairing a defective part under this warranty shall be assumed by Prospera. In except for the following expenses, which shall be assumed by the buyer.

Warranty exclusions:

This warranty does not apply to any costs, repairs, or services for the following: Repairs necessitated by use other than normal home

use. 2. Damaged resulting from misuse, abuse, accidents,

alternation or improper installation.

3. Corrective work necessitated by repairs made by anyone other than Prospera authorized service techni

Non-warranty service is provided on a "per incident" basis. Consumer will verify that the product has failed and provide information for servicing the unit. All applicable repairs, parts, shipping, handling, local tax and "per incident" fees will be charged for non-warranty repFor warranty service, please call 925-292-5978, M-F. 8:00am to 4:00pm, Pacific Standard Time. Or send email to sales@prosperacorp.com. Consumer may also mail service request to this address:

Prospera Corporation Warranty Service Livermore, CA 94551

About Prospera

Prospera develops high quality, innovative, and affordable massage products, ranging anywherefrom electronic pulse massagers to jade massagers. Prospera's products are available through leading department stores, consumer electronics stores, and major online retailers. Learn more about Prospera at www.prosperacorp.com

448 Commerce Way Livermore, CA, 94551 Tel: (925) 292 5978 Email:sales@prosperacorp.com

Prospera Corporation

Warranty card

prospera prospera

Warranty Registration Form

Product Model: Purchase Price:

__ Email: ____

Please mail to:

Email:sales@prosperacorp.com

448 Commerce Way Livermore, CA. 94551

Prospera Corporation

Product Name: _____

Retailer: Date of Purchase: ____ Last Name First Name:

Signature and date:

Tel: (925) 292 5978

User Instructions ML012 Pink Diamond Collagen Facial Mask



Step 1: Cleanse Face

Cleanse your skin with a facial cleanser designed for your skin type. Cleansing helps prepare your skin to absorb the nutrients and active ingredients from the mask, maximizing its effectiveness.



Step 2: Apply Mask

Remove the collagen sheet mask from the foil pouch and apply it to your face. Let it rest for 15-20 minutes; this allows the collagen to soak into your skin. The collagen helps smooth out wrinkles in your skin by plumping and firming your skin, making your face appear younger and smoother.

Once finished, remove the sheet mask, and apply the remaining collagen essence into your face and neck.



Step 3: Apply Moisturizer

Moisturize your skin while it's still damp. Choose a moisturizer designed for your skin type and apply a thin layer. This locks in moisture and keeps your skin hydrated, maximizing the full effects of the collagen mask.

The ML012 Pink Diamond Collagen Facial Mask can be used daily; we recommend using it at least twice per week to see and maintain results. Collagen is a potent and beneficial nutrient that your body already creates naturally but eventually slows down production as we age. With the ML012 Pink Diamond Collagen Facial Mask, you can combat these effects and boast a smooth, youthful complexion.