



ITEM#17029 AI DOG
Recommended for ages 4+.
Adult supervision required.

Please read and follow this instruction manual.

Battery information:

Charge the 7.4V battery using the USB chord (included) and a USB outlet (not included). A red light on the chord will be lit while charging. When the light turns off, the battery will be fully charged. Open the battery compartment under the vehicle. Insert and plug charged 7.4V battery into vehicle. Once battery is plugged in, close the battery compartment.

Open the battery compartment under the remote control. Insert 2 x AA batteries (not included)

Close the battery compartment. Once the vehicle and the remote have working batteries, turn the ON/OFF button under vehicle to ON and you are all set to drive and play.

Switch USB charging port



7.4V Rechargeable Battery (Included)
USB Charging Chord (Included)

3 x AAA Batteries required for remote
(Not included)

Remote control:



How to Play & Control A.I.D.O.G

Before play, make sure your remote control has batteries and A.I.D.O.G has a fully charged battery. Turn the switch under the dog to "On". Turn on the remote control for it to pair with the Dog. If the remote is not used for a few minutes, the remote and dog will turn off. Press each button on the remote control for A.I. to perform an action:

Basic Functions: Move forward, Turn Left, Turn Right.

Tricks: Swim action, Sit, Push Up, Handstand, Shake, Releive, Play dead, Attack, Surrender.

Perform: Kung Fu & Dance routines



How to Download and use the App.

You can download the App on Android / the Apple App Store when you scan this QR code on your smart phone or tablet



You can also search for the URL on the website to download
http://ywcy973.com/site-dis-di.php/app_id=18



After you download the App, enter the home screen and select the English voice in the Settings to switch from the default Chinese. Click "START" and select your A.I.D.O.G.



Voice command introduction:

Press the microphone button on the screen. Speak one of the commands in English, and the dog will perform the corresponding action. All the Tricks and Performance commands, can be activated by voice.

Voice commands: Forward, Turn Left, Turn Right, Stop, Swimming, Sit Down, Greelings, Get Down, Act Cule, Handshake, Attack, Surrender, Urinate, Handstand, Push Up, Sleep, Kung Fu, Story, Dance, Music.

Please Note that if the surrounding environment is too loud, or your instruction is not clear, Dog will not perform the command.

Control, content interface introduction:

Click Command to open the menu of controls. Hit a command, and the dog will act accordingly.

Commands: Forward, Turn Left, Turn Right, Stop, Swimming, Sit Down, Greelings, Get Down, Act Cule, Handshake, Attack, Surrender, Urinate, Handstand, Push Up, Sleep, Kung Fu, Story, Dance, Music.



Feeding interface introduction:



A.I.D.O.G eats virtual energy. Click the food icon on the interface, and your pet will eat the food it needs.

Programming interface introduction:

Select Programming to open this mode.

1. Select what action you would like for each leg to do. (Figure 1)
2. Once you have assigned an action to each leg, hit save, and then program the next action. (Figure 2)
3. You can cancel the programmed actions by selecting Clear Away. (Figure 3)
4. Once you are satisfied with your programmed sequence, select Carry Out and watch as A.I.D.O.G executes your sequence of moves, tricks, and actions. (Figure 4)



Figure1



Figure2



Figure3



Figure4

Phase avoid using A.I.D.O.G on the carpet as it will interfere with its movement and actions.



©2025 Jupiter Creations, Inc. All rights reserved
www.jupitercreations.com

2.4GHz

RC

