


EMS美眼仪说明书 说明书尺寸:170*125mm 钉装方式:骑马钉


材质:80g双胶纸











Micro interface charging

Micro interface charging


· After the controller is connected as shown in the figure above, start charging During charging, the charging/mode indicator flashes red
·After charging, the charging/mode indicator is on for a long time. At this time, 1H; After a single full charge, a single controller takes about 45 minutes. However The charging time and use time may vary depending on the gear and idle time. ⚠ be careful the water stains. Charging with water stains may cause the controller to · Please install the charging terminal in the correct direction. If the installation direction is incorrect, charging cannot be started.


· When charging for the first time after purchase, be sure to fully charge before · When it is used for the first time or at the end of a long period of time, it may only be used for a short time even if the full power state is displayed. At this


· Please use the standard USB charging cable and power adapter. Confirmation of skin suitability ⚠ be careful In case of abnormal conditions such as hair loss, redness, itching and irritation

1 Clean the inside of the arm with soap and other products, and then wipe 3 After setting to gear 1, press the two electrode heads on the arm for about 3 that the left and right electrodes are closely fitted to the skin. \cdot When the power is started, the initial gear of EMS in pull-up mode is 0. · For instructions, see "Ways of Care.". 4 Wipe off the excess eye essence and confirm whether the skin is abnormal. This product can be used if the skin is not red or hot within 24 hours.

Installation method of eye mask Install the controllers (2 off) to the eye shield. Note the device orientation of the controller.







Trim the bangs back and up to prevent the eye mask from pinching the hair.

Before use, apply eye care products (eye cream, eye essence) around the eyes before use. mistake.
• Please install the controller in the shutdown state.



When the skin surface water is insufficient, you may not feel the EMS body feeling; Therefore, please make sure that the place where the skin contacts the electrode is kept moist. Adjust the eye mask to a comfortable The fixed rural belt shall be li

♠ be careful

· Do not use cosmetics containing oil such as cosmetic oil. It may shorten the service life of the eye mask.


Wearing this product with makeup may cause discoloration of the eye mask and controller. Please wear it after removing makeup and cleaning.

· If the body feeling is not obvious, apply th

 Please adjust the fixed rural belt to an appropriate position.
 It can be used normally even if the least of the difference of facial contour, the fully fitted to the skin, care can be carried ou

 $\dot{}$ Insufficient skin moisture Please fully moisten the skin with eye cream, eye essence, etc. It is recommended t Please fully moisten the skin with eye cream, eye essence, etc. It is recommended to use Medi Lift special eye essence.

If you need to strengthen the EMS body feeling, please fully use skin care products on the four electrodes of the controller. It is recommended to use MediLift specific gel (refer to the back). If the water content of the left and right sides is different, the body feel may be different. In addition, if the measuring electrode in the controller cannot fit the skin, it will also affect the sense of body care.



· Make sure that the controller is properly installed on the eye mask before wearing.

• Please install the controller in the shutdown state. It is recommended to wear eye masks after tying up your hair.

When wearing, please pay attention to prevent the Velcro from sticking to the · Make sure that the electrodes in the eye mask (4 places in total on the left and

right) fully fit the skin. If the electrode surface is not fitted, the nursing effect may not work properly. · If the hair is smeared with an oil based care solution, please wait until the hair is dry before using this product.

Please ensure the moist state between skin and electrode. If the skin is not moist enough, the body feeling effect of EMS will be affected, which ma

Key points of nursing Before skilled operation, please use it in front of the mirror to confirm correct 1 Start up

Press the power/mode buttons of the left and right controllers simultaneous for more than 1 second. After the beep of "Di" sounds, the charge/mode ind · Please make sure that the controller is installed on the eye mask, and the start the power supply.

When starting the power supply, please set the EMS gear (strength) to gear

About 10 minutes after setting the mode, it will automatically shut down


Maintenance and inspection

2 Select nursing mode according to personal needs

Each time a beep sounds, the mode switches.

1 Pull mode (red blue light) Relaxation mode (red and

Select EMS gear (intensity) according to personal needs Press the left and right controller+/- buttons at the same time



A It is recommended to use this product once a day for 10 minutes each time. It continuous use is required, the intervashall be at least 5 hours.

A This product is not waterproof, please avoid using it in the bathroom.

 $Q \begin{array}{c} {\sf Can\,I\,use\,it\,during} \\ {\sf sleep?} \end{array} \qquad \qquad {\sf A} \quad {\sf Do\,not\,use\,this\,product\,during\,sleep}.$


The heating mode cannot adjust the gear. It takes about 1 minute to feel warn ·As shown in the figure below, the buzzer will vary depending on the gear


⚠ be careful Before the first use or skilled operation, be sure to set the gear to the first gear · If your skin feels dry, you can replenish water during use. During operation turn off the machine first and then remove the eye mask. Do not adjust the EMS gear (intensity) to the intensity of tingling. 4 After care About 10 minutes after setting the nursing mode, it will automatically shut

When the machine is turned off, a beep will sound. If you need to stop using, please press the power/mode buttons on both side ** The above frequency of use is for reference only. Please use according to your * In case of abnormal skin condition, please stop using immediately, * If continuous use is required, it is recommended to use it at an interval of more




Wipe off residual stains with a wrung wet towel. ⚠ be careful Do not place it in the state of touching cosmetics such as lotion, beauty lotion or gel.
 Do not use alkaline detergent, alcohol, thinner, gasoline, nail remover and other liquids to wipe the











Hazards (matters related to use and storage)







Please carefully read the user manual of the purchased product for

use with medilift series products.

 Sufficient make-up water, beauty lotion or gel and other moisturizing ingredients should be kept between the skin and the electrode. When the skin feels dry, please turn off the power and remove the eye When the skin feels dry, please turn off the power and remove the eye mask before replenishing water.
When the skin is short of water, the transmission of EMS will be weakened, which is easy to cause decline in use effect or skin problems.

Be sure to remove makeup and clean your face before using. If used with makeup, foundation make-up may darken the skin.

Please confirm that there is no abnormal skin condition before use. If the skin is abnormal, please stop using.

When the product is not used for a long time, please make sure that the When the product is not used for a long time, please make sure that the product is in a normal and safe state before reuse. May cause skin problems.

 Please keep an interval of more than 5 hours for continuous Please keep an interval or inforce than 3 is don't use. It may cause personal injury or body heat.

Please stop using if you feel uncomfortable or your skin is

Be sure to observe abnormal during use. If you still feel unwell after the next day, please consult a professional doctor.
■ Be sure to set the gear to the first gear (minimum) for use for the first time or before being familiar with the use. Even if the EMS body feeling is not strong, do not arbitrarily increase the

It is easy to cause skin injury. Please use it according to your skin If you feel skin tingling, please lower the EMS gear (intensity). After use, please refer to "After use" to clean the residual beauty The following items must be observed.

It may cause accidents, human injuries or mechanical failures. Use according to the skin condition.

Please stop using if the skin appears rash, inflammation, itching and other symptoms.

Please try to avoid using this product when the skin is fragile and

● Please turn off the machine before use or cleaning. When not in use, please unplug the power adapter and USB charging cable from the socket.
 In addition, do not use wet hands to plug or unplug the plug.
 ● When unplugging the power adapter and USB charging cable from the host or socket, be sure to hold the front end plug and pull it out (to avoid touching the metal part). In addition, do not use wet hands to plug or unplug the plug.
 It may cause electric shock, short circuit and fire.

🔨 Warning (power related)

 Do not use the power adapter, USB charging cable or plug when they are loose. Please consult the dealer for maintenance. Please do not get wet or rinse the power adapter and USB charging cable.
 It may cause electric shock, short circuit, fire and fault.

No touching water

.....

■ Use 100-240V AC voltage.
 Please confirm whether the power adapter and USB charging cable are plugged in properly. Be sure to confirm the plug shape and voltage before use. It may cause fire, electric shock and failure.
 ■ in case of any abnormality, please cut off the power immediately. In case of abnormal operation, smoking, abnormal noise or odor,

and maintenance.

After charging, unplug the power adapter from the socket.

Be sure to observe

Storage method

charging cable from the host and socket.

Please do not place it in the place with high temperature and humidity (near the fire source, under the hot sun, bathroom, etc.) Maintenance and inspection

The battery is running low. Please charge. If the skin is dry, please add some eye beauty liquid to keep the skin moist. This product has built-in rechargeable battery. It may cause heating,

common problem Q What are the standards for

Because the left and right faces are asymmetrical, it may lead to the difference of body feeling between the left and right faces.

At this time, the left and right EMS gears can be adjusted appropriately. Why is there a difference between left and right facial body feeling? Why do you hear A This is the sound of current flow. This is There are individual differences in response to the use of EMS.

If the symptoms do not improve the next day, please consult a professional doctor.

How much is the appropriate amount of eye beauty liquid for each use?

Q Can I use it in the bathroom?

Q Can I use it immediately after sun exposure and shaving?

A May cause skin irritation. If the skin is abnormal, please stop using immediately and consult a professional doctor. Q The skin turned red. A Due to the pressure exerted by the heater and silica gel, the skin may become red for a short time. If the skin is still red on the next day, please consult a professional doctor. Q The skin was marked with eye patches.

Product specifications Rated power supply DC5V 0.6A

Power Single controller - 1.8W Remote control - 0.25W

Use battery Polymer battery

Charging time About 1 hour ** The charging time varies so depending on the charging environment.

Usage time 45 minutes for a single controller Remote control 11.0H

Eye mask: about W624.5xH84 (mm) (including fixing strap)
Controller: about W87xH46xD15 (mm) (including electrode part)

Product weight Eye mask: about 98g Controller: about 329 /ni Product weight Eye mask: about 98g Controller: about 32g/pie texture of material Eye mask: silicone Controller: ABS resin Country of China China
manufacture

Eye mask *1, controller *2, remote control * 1
USB two in one charging cable * 1,
manual (with maintenance card) * 1

Recommended temperature

10°C~40°C

temperature 10 C-40 C

after-sale service

When cleaning, use a dirty cloth.

rechargeable battery Rechargeable batteries are consumables. (not covered by the warranty) If you need to replace the rechargeable battery, please consult the dealer or

About abandonment Please discard this product according to local regulations.This product uses lithium battery.

About Warranty ● In case of any fault during normal use, the warranty period shall be 1 year • In addition, after the warranty period expires, the customer shall bear the The fault occurred after the warranty period is expired shall be charged according to the actual maintenance cost.

The maintenance within the warranty period may also incur costs. Please ead the instructions of free maintenance regulations in detail. • In case of failure, please contact the dealer or the official general agent of

Provisions on free maintenance

dealer who purchased it for free maintenance.

2. The product warranty period is one year. During the purchase and warranty period in mainland China, if a fault occurs and needs to be detected, please bring the product and warranty card to the purchasing dealer or contact the customer service center for detection. 3. Please contact the dealer who purchased this product in advance when repaired free of charge by the dealer recorded in this book due to the use of the product by others.

5. During the warranty period, the following conditions are not included in the

of this product. If any fault occurs during use, you can take this product to the


(1) Failure and damage caused by improper use or improper maintenance and (2) Failure and damage caused by the dumping and falling of the product during use after purchase.
(3) Faults and damages caused by fire, earthquake, flood and other natural disasters, public hazards or abnormal voltage. (4) Faults and damages caused by the abnormality of other electrical equipment connected to the product. (5) When battery, consumables and other parts are replaced. (6) Faults and damages caused by non ordinary household conditions (such as commercial conditions requiring long-term use).

(7) Failure and damage caused by loading in vehicles or ships.

(8) Failure and damage caused by transportation, movement and falling after (9) Other matters beyond the scope of legal provisions or free warranty.

(10) The mandatory column of this warranty card is not filled with the purchase date, customer name, dealer and other information, or without the seal of the dealer, and the information filled in is changed. * This warranty card has certain restrictions on the time and conditions of free maintenance, but it does not limit the rights that customers should enjoy in law, In case of any conflict with the laws and regulations of Chinese Mainland, the current laws and regulations shall prevail.

** The product performance deterioration, consumption and consumables (such as batteries) beyond the warranty period due to natural use are excluded



product and the warranty card to the dealer where you purchased it for repair.

If the blank column of this card is not filled with the purchase date or This warranty card is not acceptable to be reissued, please keep it properly.

● If the product has not been used for a long time, please make sure that the product is in a normal and safe state before use.
● If the operation of this product is abnormal, refer to the contents of "Suspected fault" to confirm the fault before consulting after-sales maintenance. If the fault still cannot be eliminated, please consult the dealer or the official general agent of Yameng China. agent of Yameng China.

● If the product fails or is damaged, you can contact the local dealer or the official general agent of Yameng China.

The battery margin is reduced, please charge it in time. It is recommended to use it for about 10 minutes each time.

** About 10 minutes after the mode is set, the power will be automatically turned off. increased or reduced according to the skin ※ When the skin feels abnormal, please stop using it immediately.

