



**STABILITY**



**PORTABILITY**



**ADJUSTABILITY**



**THICK CUSHION**

# HEATED MASSAGE FOLDABLE RECLINING **STADIUM SEAT** USER MANUAL

Thank you for choosing the Alpcour Foldable Reclining Stadium Seat. This manual will guide you through the features, details, and instructions for using your new stadium seat. Enjoy ultimate comfort and convenience at your favorite events!

## Features

### HEATING FUNCTION

Heating Function with Three Options (Green: Low, Blue: Medium, Red: High)



### MASSAGE FUNCTION

Massage Function with Three Gears (Red: First, Blue: Second, Green: Third) and Two Vibration Levels



### THREE RECLINING POSITIONS



### TWO BACKREST HEIGHT OPTIONS



### LARGE FRONT POCKET & CUP HOLDER



### LARGE BACK POCKET



### FOLDABLE HOOK FOR BAGS



### COMFORTABLE CARRY HANDLE



### 2 BLEACHER HOOKS & ANTI-SLIP RUBBER BOTTOMS



### EASY TO CARRY SHOULDER STRAPS



### SUPER THICK CUSHION



### SIMPLE UNFOLD & FOLD



# Instructions

## Setting Up Your Seat

### Unfolding the Seat

- Place on a flat surface.
- Pull the backrest up to click into your desired reclining position.

### Adjusting the Backrest

Recline: Pull up the backrest to click into one of the three positions.

Unrecline: Push the back support forward until it folds back.

### Changing Backrest Height

- Press the two side buttons at the bottom of the backrest.
- Adjust to your preferred height and release to lock.

## Using the Bleacher Hooks

- Open the Velcro flaps at the bottom.
- Unfold the hooks and attach them to the bleachers or benches.
- Close the flaps for storage..

## Heating Instructions

### Charge the Power Bank

Ensure the power bank is fully charged using the provided USB cable.

### Plug In

Connect the USB cord to the charged power bank.

### Turn On

Press and hold the power button for three seconds.

### Select Heat Setting

Press the power button to change the setting:

- Green: Low
- Blue: Medium
- Red: High

## Massage Instructions

### Turn On

Press and hold the massage button for three seconds.

### Select Massage Gear

Press the massage button to change gears:

- Red: First Gear
- Blue: Second Gear
- Green: Third Gear

### Adjust Vibration Levels

- Press the massage button to switch between high and low vibration levels.

## Portability Carrying Your Seat:

- Use the carry handle or shoulder strap for easy transport.

## Storage Options

**Front Pocket & Cup Holder:** Open the flaps to use. Choose one or both.

**Back Pocket:** Use the large back pocket for additional items.



## Warranty and Contact Information

Register for Our 1-Year Warranty Warranty Information:

**1 Year Unlimited Warranty:** We stand by our products. If you encounter any issues, do not return to the retailer. Contact us directly for prompt and friendly customer service.

**Email:** [info@alpcour.com](mailto:info@alpcour.com) **Warranty Details:** [www.alpcour.com/warranty](http://www.alpcour.com/warranty)

**Contact Us Website:** [www.alpcour.com/contact-us](http://www.alpcour.com/contact-us)

## Explore More

**Full Catalog:** Check out our full catalog for a wide range of stadium products and other sports and outdoor gear.

Thank you for choosing Alpcour. Enjoy your events with ultimate comfort and convenience!