



MAX-RELAX

Heated Massage Stadium Seat

Quickstart Guide

Thanks for choosing our product. The Heated Massage Stadium Seat is specially designed to provide the maximum relaxing seating comfort on the go, even in cold weather. It will turn any bench or bleacher into a comfortable chair with back massage relaxation. The seat is suitable for any outdoor locations such as in stadiums, playing field, boats, camp grounds, picnics, etc.

Product Features


- **Portable:** The seat is lightweight and has adjustable backpack straps which makes carrying it from one place to the other easy.
- **Versatile:** The seat can be adjusted to six different positions and it features two cup holders, a side pocket, and a large back pocket for your phone and other valuables.
- **Waterproof:** It is designed with 600D waterproof material, reinforced PVC and antiskid material. These protect the seat from rain, water or any form of spillage.
- **Anti-slip:** The seat is designed with anti-skid PVC material on the underside which allows it stay on a flat surface without moving around or slipping. It also has a bleacher hook to keep the seat sturdy on bleachers or backless bench.
- **Heated:** The seat is equipped with a heating element to keep you warm in cold weather conditions. It can heat up to 110F.
- **Massage:** The seat is equipped with 3 different massage gears and various speed levels for your maximum relaxed comfort

How To Use


1. Remove reclining seat from the package and lay flat on a levelled surface/ground.




2. Place one hand on the seat then pull the backrest up into your desired position. You should hear a click sound as the backrest is pulled into the six different positions.



3. If using on a backless bench, unzip the pocket located underneath the seat to reveal the bleacher hook then fasten the hook on the bench to secure the seat in place.




4. To make the seat wider, simply hold on to the armrests when unfolding the chair, then pull the backrest forward as normal. The armrests should stay in place with the backrest thus creating more space.




How To Activate The Heater Function


1. Plug USB cord into a battery pack.
2. Press and hold the power button for three seconds to turn on the heater.
3. There are three heating options in the seat. Press the power button repeatedly to change to another heat setting indicated by the colours.



High



Med



Low


Red - High heat

Blue - Medium heat


Green - Low heat

How To Activate The Massage Function


1. Make sure the USB cord is plugged into a battery pack.
2. Press and hold the massage button for three seconds to turn on the massage function.
3. There are three massage gear options in the seat. Press the massage button repeatedly to change to another massage gear option setting indicated by the colours. Each gear option has two vibration levels: high and low, which is indicated by the colour blinking frequency. To switch between vibration levels, press the massage button repeatedly.



First gear



Second gear



Third gear


Red - First gear

Blue - Second gear


Green - Third gear

How To Fold Down

Fold the backrest all the way forward up to 45 degrees, then push backward to return to flat position.



Can be worn as a backpack or carried by the straps.



Enjoy Sitting On The Go

The seat is available in two different width sizes and various colors to suit your preference.

Check out our full line of stadium seats to suit your every style and budget



www.alpcour.com | info@alpcour.com