


gemini[®]



Gemini Home Speaker BRS-180


geminisound.com
458 Florida Grove Rd, Perth Amboy, NJ 08861, USA

Designed and engineered in the USA Manufactured in China
Gemini is a registered trademark of P2B Trading Co., Inc.,
under license to ICAD Holdings LLC.


Other stated company, product, or technology names/logos are the trademarks or registered trademarks of their respective companies. The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ICAD Holdings LLC is under license. Other trademarks and trade names are those of their respective owners.

WHAT'S IN THE BOX


A: Gemini Home Speaker
B: USB-C Charging Cable
C: User manual



A




B



C

PRODUCT OVERVIEW



- ①  **Long press 2S:** power on/off
Short press 1 time: activate voice assistant
Short press twice: play/pause; pick up/hang up call
Short press 3 times: reject incoming call
- ②  **Short press 1 time:** for previous song/sleep sound; decrease hour/minute number for clock setting
Long press: reduce volume
- ③  **Short press 1 time:** for next song/sleep sound; increase hour/minute number for clock setting
Long press: increase volume

BASIC FUNCTION

- ④  **Short press:** adjust the brightness of display (100% - 50% - off); jump between hour and minute when adjust clock
Long press 2S: enter into clock setting mode; confirm your final choice on hour/minute number during clock setting
- ⑤  **Short press:** switch LED lighting mode
Long press 2S: turn on/off LED light
- ⑥  **Short press:** switch modes (bluetooth mode - sleeping mode - RTC mode - PC mode)
Short press twice: disconnect bluetooth
- ⑦  LED light
- ⑧  Type-C charging port
- ⑨  Calling MIC
- ⑩  Clock
- ⑪  Status indicator
- ⑫  AM
- ⑬  PM

OPERATION GUIDE


1. Power On/Off

Long press button “” 2S to power on/off.

2. Bluetooth Mode

Long press button “” 2S to power on, speaker will enter into bluetooth pairing mode, the blue indicator will flash. Choose “Gemini” in your bluetooth list, there will be prompt tone once connected successfully, and the blue indicator will be normally on. Now, you can play music.


Remark: once connected with your iOS phone, it's time display will synchronize with your phone's time automatically.



OPERATION GUIDE

3. When under Bluetooth/Sleeping Mode

Short press button “⏮” twice for play/pause. Short press button “>” for next song, long press button “>” for volume“+”. Short press button “<” for previous song, long press button “<” for volume“-”.




4. Clock Setting

After power on, long press button “⌚” 2S to enter into clock setting mode and hour number will flash first.

1). Now you can reset hour number directly, short press button “<” to decrease, short press button “>” to increase, long press button “⌚” 2S or no any action around 5S to select your final hour number.

2). Short press button “⌚” to jump between hour and minute, so if you want reset minute number, just short press button “⌚” and minute number will flash, then short press button “<” to decrease, short press button “>” to increase, long press button “⌚” 2S or no any action around 5S to select your final minute number.



OPERATION GUIDE

5. Different Mode Setting

1). Bluetooth mode

After power on, the default mode is bluetooth mode, short press button “” to switch modes (bluetooth mode - sleeping mode - RTC mode - PC mode).

2). Sleeping mode


When under sleeping mode, sleeping sound will play one by one automatically, the default playing time is 15 minutes, long press button “” 2S to reset playing time (15 minutes - 30 minutes - 60 minutes - all the time).

3). RTC mode

When under RTC (Real Time Clock) mode, there is only clock and alarm display for battery save.

4). PC mode

When under PC mode, you can revise the sleeping sounds in this speaker device.



6. Custom Sleep Sounds (PC Mode)


This speaker includes 16 built-in sleep sounds, and you can also add your own. When you connect the speaker to your computer using the included USB-C cable, a fourth mode - PC Mode - will appear. The speaker will show up on your computer as an external drive, allowing you to delete any of the existing sounds (back them up first if you want to keep them) and replace them with your own MP3 files. After copying your files, safely eject the device and your custom sounds will be available in Sleep Mode.

OPERATION GUIDE


7. Calling

When a call is coming, short press button “

During a call conversation, short press button “A line drawing of a smartphone. The screen displays an incoming call notification with the text "Incoming Call" and a small phone icon. Below the screen are two circular home buttons.




8. LED Lighting Mode

After turning on LED light, short press button “A line drawing of the same electronic device as in the previous image. The digital display now shows "07 00:00:". A button with a sun icon is labeled "Sun button" with a line pointing to it.

OPERATION GUIDE

9. LED Clock Brightness

Short press button “” to adjust the brightness of LED displays (100% brightness - 50% brightness - off)



10. Power Saving

In the following cases, this speaker device will enter into RTC mode for power saving.

- 1). Under sleeping mode, when the playing time (15/30/60 minutes) you set is over.
- 2). Under Bluetooth mode, when nothing is connected after 10 minutes.


11. Charging

Use supplied USB-C charging cable


Use an output source 5V/1A (or above)

Charge when you hear low battery prompt tone or the indicator flash red.

The red indicator will be normally on while charging and switch off after fully charged.



BASIC FUNCTION



LED light	Total 8 LED lighting modes
LED display	Clock; volume level; timer; sleeping sound number
Status indicator	Power on (blue indicator)
	Low battery (red indicator flash)
	Charging (red indicator normally on)
	Fully charged (red indicator off)

SPECIFICATIONS

Product Name	BRS-180
Bluetooth Version	5.3
Battery Capacity	3.7V/1500mAh
Playing Time	5-6 hours (at 50% volume, LED light off)
Talking Time	5-6 hours
Charging Time	3 hours
Charging Current	5V $\pm$ 0.8A
Speaker Unit	6W/4 Ω
Product Size	101x101x57.5mm
Product Weight	280g $\pm$ 50

FREQUENTLY ASKED QUESTIONS

Q1: What kind of charger should we use for the speaker?

A: All common USB chargers can be used, while we suggest the ones 5V/1.5A or above 1.5A.

Q2: What if there is noise or discontinuous sound during playing?

A: The speaker can be normally used within 10m under no obstruction environment. If it is beyond 10m or with obstruction, there might be noise or discontinuous sound.

Q3: The Speaker automatically enters power saving mode after power on without any operation.

A: If Bluetooth® pairing is not completed within 10 minutes of powering on, the device will automatically enter power saving mode to conserve battery power.

Q4: Why does the speaker cannot connect the once-paired cellphone?

A: First, remove the speaker's paired name from the cellphone's Bluetooth list and then restart pairing.

Q5: When speaker can not be turned on or used normally.

A: Please charge it for some time, then long press power on button 10-30s to reset.

Q6: Why can't the speaker sync time with my phone via Bluetooth?

A: When connecting, grant permission for the speaker to access phone information. Some phones may not support time synchronization. Try using a different phone.

Safety & Precautions

Notes:

1. Please read this manual carefully before use and keep it properly.
2. For the first use, please fully charge the product.
3. Pls use certificated adapter that has passed national safety certification.
4. If you do not use the product for a long time, be sure to charge it once within a month at least to maintain its performance.
5. Do not use this product in an extremely cold or hot environment, such as temperature beyond the range of 5°C-35°C. If use it beyond the above range, the product may stop automatically to protect the internal circuit.
6. When charging it in a high temperature environment, the product may automatically stop charging to protect the battery. At this time, the charging indicator usually ashes quickly to indicate that the charging environmental temperature or the product internal temperature is too high.
7. Storage environment temperature: -5 ~ 35°C RH < 70% (recommended 25°C±5).

Important safety instructions:

1. Do not disassemble or repair this speaker personally, otherwise it may cause product damage or personally injury.
2. Do not use it in dusty, humid, dry, and high-temperature environment.
3. Do not place this product near a heat source, or a place with direct sunlight, a lot of dust, or mechanical vibration.
4. In order to reduce the risk of fire, please do not cover this product with newspapers, tablecloths, curtains etc., during use.
5. If the product has a waterproof feature, please do not exceed the nominal parameter range when using it.
6. When the product is damaged (such as the power cord or plug is damaged, liquid enters or objects fall into the device, unable to operate normally or falls), it must be repaired.
7. When the product is fully charged, do not connect it to the charger for further long time charging.
8. The maximum ambient temperature should not exceed 40°C.

*This speaker supports mobile phones/ tablets/ PCs etc. Here this User Manual is illustrated base on mobile phones.

Responsible Party Name:

ICAD Holdings LLC

Company address:

458 Florida Grove Road
Perth Amboy, NJ, 08861 USA

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. The operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and then on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to a different outlet so that the equipment and receiver are on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by **ICAD Holdings LLC** may void the FCC authorization to operate this device. **Note:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The device is installed and operated without restriction.
FCC ID: 2BRR7-BRS180

LEGALITY & SAFETY

The device is not intended for use by people (including children) with reduced physical, sensory or mental capacity. People who have not read the manual, unless they have received an explanation by someone responsible for their safety, should not use this unit. Children should be monitored to ensure that they do not play with the device. The device should always be readily accessible. The device should not be exposed to water. No objects filled with liquids, such as vases, shall be placed on the device. Always leave a minimum distance of 10 cm around the unit to ensure sufficient ventilation. Open flame sources, such as candles, should not be placed on top of the device. The device is intended for use only in a temperate climate. At full volume, prolonged listening may damage your hearing and cause temporary or permanent deafness, hearing drone, tinnitus, or hyperacusis.

Listening at high volume is not recommended. One hour per day is not recommended either. Danger of explosion if battery is incorrectly replaced or not replaced by the same type or equivalent. The battery should not be exposed to excessive heat such as sunshine or fire. Different types of batteries, or new and used batteries, should not be mixed. The battery must be installed according to its polarity. If the battery is worn, it must be removed from the product. The battery must be disposed of safely. Always use collection bins to protect the environment.

The battery can only be replaced by the maker of this product, the sales department, or a qualified person. Switch the device off where the use of the device is not allowed or where there is a risk of causing interference or danger - for examples: on an aircraft, or near medical equipment, fuel, chemicals or blasting sites. Check the current laws and regulations regarding the use of this device in the areas where you drive. Do not handle the device when driving.

Concentrate fully on driving. All wireless devices are susceptible to interference which may affect their performance. All our devices conform to international/national standards and regulations, and we aim to limit user exposure to electromagnetic fields. These standards and regulations were adopted after the completion of extensive scientific research. This research established no link between the use of the mobile headset and any adverse effects on health if the device is used in accordance with standard practices. Only qualified people are authorized to install or repair this product. Only use batteries, chargers and other accessories which are compatible with this equipment. Do not connect incompatible products. This equipment is not waterproof. Keep it dry. Keep your device in a safe place, out of the reach of young children. The device contains small parts which may present a choking hazard to kids.

gemini[®]

At Gemini, our highest priority is making your experience unforgettable.
Need help with setting up, troubleshooting, or looking for some tips?
We're here for you, Monday through Friday 9AM

WELCOME TO THE GEMINI FAMILY!



hello@geminijsound.com



1-844-GEMINI9



www.geminijsound.com

   
@GeminiSoundHQ

RoHS CE FCC  