Quick set up guide:

TOKK™ CAM S9+



1. Power Button
2. Mode Button
3. Micro SD Slot (TF card)
4. Reset Button
5. USB Port (Power Switch)
6. Mic
7. PIR
8. Light Sensor
9. Photosensitivity
10. Lens

Thank you for your order. We hope you will Enjoy your new TOKK CAM S9+ Camera.
Below is our quick set up guide. If you want more details please refer to the complete instruction manual.
If you encounter any issues setting up your new camera, please do not hesitate to call us and we will be very happy to help you. Our customer service phone number is +1 858 999 2114 ext 1.

First time set up:

A



1- If you have a SD card, insert it (3), if you do not, don't worry, please continue (you can always install it later.)
2-Turn on the camera (1) and turn the mode switch (2) to WIFI, check out figure (A)
3-Scan QR code (B) to download the application called "Fowl" on your smart device, you can also open your browser on your smart device and type:
https://apps.apple.com/us/app/fowl/id1509600438 to dowload the app.

B

4-Open the app "Fowl", Allow the App to send notifications and select Agree to the privacy agreement.
5- Login: you can type an email and create a password (to retrieve your login, this will be useful), but you do not have to if you do not want to, in this case select Register Now.
Then create a user name and a password, press submit.
Allow the app to have access to your location (Allow while using App is recommended). Then close the app.
6- Go to WIFI settings on your smart device.
7- Wait until your camera name appears "@MC-XXXXXX", when it appears select it (disregard messages like "unsecured network, or"/no Internet access...") as long as "@MC-XXXXXX", is selected as your wifi network go to the next step.
8- Open the app "Fowl" again
9- Your device will automatically appears, just press the play button in the middle of the screen to check out the live feed.
10-Add your wifi, so you can access the camera from outside your home or office: open settings in the app via the wheel icon, open wifi settings, select your wifi from the list, and type your password, then type ok, and confirm your password. Then login again using your password , you are now all set up.

Thanks to its technology, when you leave the TOKK CAM S9+ on and it is connected to your Wifi, TOKK CAM S9+ will automatically shut down and turn on when it detects movement, it will trigger a notification to your phone.

PRED Technologies USA Inc.
7855 Fay Avenue
La Jolla, CA 92037

1-858-999-2114
contact@predtechnologies.com
www.predtechnologies.com

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. ©2017 Pred Technologies. All rights reserved.

Quick set up guide for TOKK™ CAM Fowl App

PRED TECHNOLOGIES™

APP home page



To add another Camera

To access the live view

To access system settings
-Share this cam to another app
-If more than one Cam installed on App
move this cam on top.
-Cloud storage options

To access your account

To come back to main page

To access the video Recordings

Individual Cam home page



To go back

Full settings

live view

Change Image Quality

Tap to take a picture (stored on your Phone)

Tap to record a video (stored on your Phone)

Rotate live view

Talk (For Cam X1, F10, F3, F3+ only)

Listen to live view

Rotate (For Cam X1, F10, F3, F3+ only)

Rotate (For Cam X1, F10, F3, F3+ only)

Trigger an Alarm Sound (For Cam X1, F10, F3, F3+ only)

Trigger Trigger light (For Cam X1, F10, F3, F3+ only)

Access all the other Cameras, If you have more than one

To go back to live view

To Access the SD card Recordings

To Access the Cloud Storage Recordings



To change the name of your Camera

To open QR code to share Camera to another Fowl App

Move this cam up to the first Camera (if more than 1 cam)

Open the sub settings for Image Settings (night vision, diplay time and date, change live view settings, adjust brightness and contrast)

To open Cloud Storage settings and payments if needed

Add the cam to your home Wifi

Check Micro SD card capacity/settings

To open Motion Detection settings and/ notifications and recording time

LED on or Off

To check if software update needed

To re start the App

To delete the camera