

ALL-IN-ONE APPLE CHARGING STATION

Item No. 208116


User Guide

Thank you for purchasing the All-In-One Apple Charging Station. Please take a few minutes to read this guide and store it for future reference.

FEATURES

- Charges up to 3 Apple devices simultaneously, including iPhone, Apple Watch and AirPods
[NOTE: Apple Watch charging cable and AirPods charger are not included]
- Also charges Samsung Galaxy S8, Note 8 and other newer Android devices
- Space-saving design
- Wireless charging pad
- 2 USB charging ports
- Plugs into a USB port or an AC outlet [AC adapter not included]
- Dimensions: 8" L x 6" W x 4" H. 0.75 lbs.

PRODUCT DESCRIPTION



SET UP

1. Use your original Apple Watch® charger with a cable length of 1 ft. or 3 ft.
2. Remove the tower to reveal the built-in USB ports.
3. Place the watch charger in the opening provided and plug into one of the USB ports.
4. Plug a standard Apple Lightning cable into other USB port.
5. Replace the tower, making sure to hide the excess cable.
6. Place the head of the Lightning cable through the provided cover.
7. Use the included USB-C cable to plug this device into a USB power source or an AC outlet [AC adapter not included].

WIRELESS CHARGING

The wireless charging feature is compatible with most newer phones, including iPhone 8 and newer devices, and Samsung Galaxy S8, Note 8 and newer devices. If you are not sure if your phone is enabled for wireless charging, please consult your owner's manual.

Compatible devices include:

- iPhone 11/11Pro/ iPhone XS / XR / XS Max / X / iPhone 8 / 8 Plus +
- Samsung Galaxy S8, Note 8 and newer
- Google Pixel 1 & 2

NOTE: For fastest wireless charging, you may wish to use an AC wall adapter or USB port that is 1A or above [2.4A max]. [NOTE: AC wall adapter not included.]

TROUBLESHOOTING

- If you are experiencing issues with wireless charging, make sure your phone is centered on the charger [see image below].



INCORRECT PLACEMENT



CORRECT PLACEMENT

- If you are experiencing slow charging, be sure to use an AC wall adapter or a USB port that is 1A or above [2.4A max] for optimal charging speeds [AC wall adapter not included].
- The wireless charging pad can charge through cases up to 5mm. If your case is thicker than 5mm it may be interfering with the wireless charging process.

SPECIFICATIONS

Wireless charger compatibility: iPhone 8 and newer; Samsung Galaxy S8, Note 8 and newer, Google Pixel 1 & 2 and other newer devices

Input: 5V 2A USB-C Port

Output: 5V/0.5A for USB 1, 5V/0.5A for USB 2

Wireless output: 5W /7.5W /10W

Product weight: 0.75 lbs.

Product dimensions: 8" L x 6" W x 4" H

SAFETY WARNINGS

- Do not disassemble this device
- Keep this device away from extreme heat
- Keep this device away from water
- Keep this device away from magnetic fields
- Use only the proper power adapter as described in this manual
- If this device becomes too hot, remove your phone and unplug the device from the power immediately. The device may shut off on its own if it becomes too hot. Wait until it is completely cool to use again.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: [1] This device may not cause harmful interference, and [2] this device must accept any interference received, including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

