





<b>Before using the product, please read this manual carefully and keep for future reference</b>		<b>Safety Precautions</b>	
<hr/>		<hr/>	
Safety Precautions .....	1	•Children or people with disabilities need to use this device with caution.	
Components .....	3	• Please stop using product immediately and consult your physician if you feel any discomfort.	
Product Structure .....	3	• If the device or charger, or rechargeable line has been damaged, please do not use it.	
Button Display .....	4	• Before charging, please ensure that the charger and the product are dry.	
Use Operation Method .....	5	• Do not use other devices when using this machine.	
Charging .....	6	• The device is for personal use only.	
Maintenance and Protection .....	7	• It is recommended to use fifteen minutes each time.	
Troubleshooting .....	8	• Do not drag the product on the ground, or pull the power line to move the product.	
Technical Parameters .....	8	• Do not use this device if you have recently had eye surgery, glaucoma, cataract, retinal detachment, or any other sort of eye related issue unless approved by a doctor.	
		- 1 -	

<b>Safety Precautions</b>		<b>Components and Functions</b>	
<hr/>		<hr/>	
• People who have medical electronic equipment such as cardiac pacemaker, please do not use this product.			① ❶ (On/Off) / Mode ② ❷ Big Screen ③ ❸ USB charge ④ ❹ Control panel
• Do not use this product if you are suffering from cancer, heart disease, hypertension etc.Please consult your doctor prior to use.			⑤ ❺ Elastic band ⑥ ❻ Cloth cover
• Do not use device if you have a fever (above 38C / 100F)			
• When in use, please tilt head slightly up.			
• Do not remove internal components of the product without permission, in order to avoid the possibility of machine failure.			
• Do not attempt to modify, repair, or alter the product in any way.			
• Do not use a power source other than the rated voltage, so as not to cause a fire or damage to the product.			
• When unplugging the power cord, grasp the power cord plug, not the cord.			
• Please use the product matching charger, if you need to replace please contact Vaivita Wellness to replace.			
- 2 -		- 3 -	

<b>Button Display</b>		<b>Use Operation Method</b>	
<hr/>		<hr/>	
		1.Long press the "❶ / Mode " button to switch the machine on.	
		2.Press the power button, vibration, air pressure, heating and music are automatically turned on, and the volume is 7.	
		3. Short press the "on/off" button to change the mode. The mode "01-04" is optional.	
		4. Mode "01" pressure and music are turned on.	
		5. Mode "02" air pressure, heating and music are turned on.	
		6. Mode "03" heat compress and music are turned on.	
		7. Mode "04" heating, air pressure, vibration and music are all on.	
		8. "+,-" button, long press the "+" button to turn on and off the music. Short press the "+,-" to increase or decrease the volume level. There are 10 Volume level.	
		9. Charging. Use TYPE-C USB for charging. Power supply: DC5V 1A or above. When charging, the battery icon scrolls, and the battery icon is always on when it is fully charged.	
① Compression Therapy    ② Vibration    ③ Bluetooth Speaker    ④ Heat Therapy		Caution:	
		1. The device has a 15-minute auto-shutoff feature and will turn off once 15 minutes are up.	
		2. It is recommended to remove contact lenses and any hair ornaments while using the device.	
		Before wearing, please put the cloth cover to close your eyes, adjust the elastic band, until you reach the most comfortable position.	
		Bluetooth function: After the Eye massager is turned on, the mobile phone Bluetooth searches for ME10, and after connection, you can play your favorite music through the mobile phone.	
		- 4 -	
		- 5 -	

## Charging

- Please open the box of the product, connecting the USB cable inside the box to your phone charger or mobile power supply , and then insert the DC plug into products charging jack.
- Insert the plug of the charger into an outlet in 100-240v, 50/60Hz.
- The charger is connected, the charging indicator will light up.
- It will takes about 3 hours to fill the battery.

### Caution:

During charging, the product can not be used.

Please use the build-in charger.

Do not squeeze the power cord to avoid damage caused.

- 6 -

## Maintenance and Protection

### Maintenance

- If the product is dirty, please wipe with a soft cloth or use a cotton ball with alcohol.

Caution

Water or corrosive liquid to clean this product is prohibited.

### Protection:

- Keep the appliance in a cool, dry safe place after use.
- Do not place heavy objects on the product.


Caution

Place don't place the machine in high temperature or hot water.

- 7 -

<b>Troubleshooting</b>		<b>Warnings:</b>	
<hr/>		<hr/>	
Phenomenon	Possible Causes	CONTRAINDICATIONS:	
Unable to boot	Switch is not open	Please read the instructions carefully before use and use this product in the correct order.	
	Battery is exhausted	Please keep out of reach of children. This device is not recommended for use on children under the age of 12.	
	Session ended	No modification of this device is allowed.	
Cannot charge	Plug is not plugged in	-Do not place magnets, metal or conductive objects on the body of the device as it may cause malfunction.	
Indicator light dark or flicker	Low battery	-Do not wipe with alkaline detergent, alcohol, thinner, gasoline, nail polish remover, etc.	
The pressure is too weak		-If not in use for a long time, please make sure that the instrument is fully charged.	
		-Please stop using it immediately when there is abnormal heat, so as not to cause burns and fires and other safety issues.	
		-When the power cord is damaged, please do not use it to avoid short circuit and fire.	
		-DO NOT submerge the device into water as it will malfunction and/or cause injury.	
		-Do not place near flammable materials (spray, oil, natural gas, etc.)	
		-If product has abnormal noise, odor or smoke, do not disassemble it at will, please contact the customer service email: hello@vaivitawellness.com	
		- 8 -	
		- 9 -	

<b>Important Safety Information:</b>		<b>What is Not Covered by this Warranty?</b>	
- If the product is faulty, please contact the customer service center, please do not disassemble or modify the machine by yourself. Do not use or charge device with power adapter that is damaged and/or faulty. Do not harshly bend or abuse the wire of USB charging cord. Do not attempt to take the device apart. Device is not serviceable by user. This will void any warranty.		This warranty does not cover: wear, tear or deterioration, damage, failure caused by neglect, abuse or misuse, improper care, impact or insertion of foreign objects, use with a voltage connector, repair or alteration carried out by parties other than Vaivita Wellness or its authorized agents, or loss of device.	
Stop using the device immediately if you think it is defective. Please contact Client Care at hello@vaivitawellness.com		<b>What Will Vaivita Wellness do if your device is defective?</b>	
Product Representation: Vaivita Wellness is constantly improving its products with the latest technology. As a result, the actual product may differ slightly from the product shown in the images on the packaging and in the user guide.		If you discover a defect in your device covered by the warranty, contact Customer Care at hello@vaivitawellness.com for assistance. If we confirm a defect covered by this warranty, Vaivita Wellness will, at its sole discretion, decide whether to replace your device with either a new or refurbished device. If we find that your device is not defective, as determined by Vaivita Wellness in its sole discretion, we will notify you and return the device to you. All warranty services must be authorized and performed by Vaivita Wellness or a service provide authorized by Vaivita Wellness.	
<b>WARRANTY INFORMATION:</b>			
Our warranty is limited to the terms set out below:			
<b>What is Covered in the Warranty?</b>			
This 1-year warranty covers only defects in materials and workmanship in your AQUAFLOSS when purchased through an authorized partner or directly from Vaivita Wellness.			
- 10 -		- 11 -	

<b>WARRANTY LIMITATION &amp; DISCLAIMERS</b>		<b>NOMA EYE MASSAGER</b>	
This warranty gives you specific legal rights and is in addition to your statutory rights. Your remedies for the breach of this limited warranty are limited solely to the repair and replacement of your device as set forth in this warranty statement.			
To the maximum extent permitted by applicable law, Vaivita Wellness disclaims all implied warranties. In no event shall Vaivita Wellness be liable for any special, incidental, consequential, punitive, or indirect damages based upon breach of warranty, breach of contract tort (including negligence or strict product liability),or otherwise, even if Vaivita Wellness is advised or aware such damages may arise. Such damages include but are not limited to: loss of device, cost of any substitute equipment, the claims of third parties, or damage to property.		Client Care: For information regarding device usage, warranty, and additional information, please contact Client Care at Hello@vaivitawellness.com	
If the applicable law does not allow limits on warranties, or on the remedies for breach in certain transactions, the limits in this paragraph and the disclaimer or exceptions from warranty may not apply.T his limitation does not apply to claims for death or personal injury caused by a defect in the device or any other liability that cannot be excluded or limited by law.		Disclaimer: This product is not intended to diagnose, cure or prevent any disease.Vaivita Wellness makes no claims, representations, or warranties regarding the ability of this product to cure any mental, physical, or skin conditions. A qualified health professional should be consulted with regards to any condition requiring medical attention.	
These warranty terms, conditions, and limitations allocate the risks of product failure between Vaivita Wellness and you, the purchaser of a Vaivita Wellness branded device. This allocation is recognized by both parties and acknowledge that you have read these terms, conditions, and limitations, understand them, and are bound by them.		www.vaivitawellness.com Hello@vaivitawellness.com Item Number: VV-EYEMASSAGE AST-214	
- 12 -		- 13 -	