# **User Guide** (Cover)

(Front)

#### Legal Information

#### **FCC Information**

his device complies with Part 15 of the FCC Rules

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- which the receiver is connected.
  -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
This device has been evaluated to meet general RF exposure requirements.
The device can be used in portable exposure conditions without restriction.

Rating Label Definitions

Direct Current

This symbol represents FCC Declaration of Conformity and compliance.

Printed in China/Designed in the U.S. v1.05/2020

#### Warranty Information

Territory: United States/Canada

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product (including any accessories included in the original packaging) as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer ourchaser against defects in materials and workmanship ("Warranty") as follows:

To obtain warranty service

- Visit our website at www.southerntelecom.com
   Click on Product Support
   Select the Brand of your device
   Select Service Request and fill out the form to begin your inquiry

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier

packaged.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. BISTRIBUTOR FORTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTIES AFTER THE EXPRESS WARRANTE AND ANY EXPONDING THE PROPERS OF THE PROPERS OF THE CONTROL OF THE PROPERS OF THE CONTROL FROM THE PROPERS OF THE CONTROL FROM THE PROPERS OF THE CONTROL OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTORS SOLE DISCRETION ARE THE EXCLUSIVE REMEDISE OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROPITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSES OR INABILITY TO USE THE PROPULCY EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY, NOTWITHSTANDING THE OREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEPT THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR THIS WARRANTY SHALL NOT EXTEND TO ANYONG OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incident consequential damages or allow limitations on warranties, so limitation or exclusions m ort apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.



## **UV-C Sanitizer** Portable Case



Instruction Manual OLID1087

## Getting Started

#### READ ALL INSTRUCTIONS CAREFULLY **BEFORE USE AND KEEP THIS MANUAL**

Questions & Support

If you have any questions or problems concerning this product, please visit our website at SouthernTelecom.com and click on Product Support.


- In the Box
   OLID1087 UV-C Sanitizer (x1)
- Power Cable (x1)
   User Manual (x1)

### ▲ Important Safety Instructions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual. Never use the device for anything other than its intended purpose.
  This device is NOT a substitute for proper medical equipment or
- ONLY use the supplied power cable
- Do not open this product or attempt to repair the unit yourself should it not be working. Doing so risks fire, shock or injury.
- The device contains an safety feature that powers it off automatically when the cover is opened. Do **NOT** disable this Never allow UV-C light to shine in
- safety reature. **Never allow UV-C light to shine in eyes or on skin**When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.

  It is recommended that the device be covered to protect it from
- exposure to dust if it will not be in use for a long period of time
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
   Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the power cable when not in use.
- · Do not pull the power cable to disconnect, or use the cable as a
- Do not use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.

#### Location of Controls



1x Press: Fast Sanitize (90s) 2x Press: Deep Sanitize (5m)

### Setting Up

Place the UV sanitizer on a flat, solid, stable surface

Plug the small connector of the included USB power cable into the power port on the right of the sanitizer. Plug the large connector into a USB power source such as the USB port


a computer, or a 5V/1.5A

USB adapter (not included) and plug into a wall outlet.



### Setting Up (Cont'd)

Set up the sanitizer & connect to power. Open the cover of the sanitizer from the front, and place the device you would like to clean inside of the sanitizer. Close the lid





Using the UV Sanitizer

The UV sanitizer has two sanitization modes: Fast Sanitize mode and Deep Sanitize mode.

- Press the [Power] button once (1x) to Fast Sanitize
- Press the [Power] button once (ix) to Fast Sanitize
   Press the [Power] button twice (2x) to Deep Sanitize.
   When Fast Sanitize mode is activated, the LED indicator on the lid of the sanitizer will turn BLUE, and the sanitizer will sterilize for the next 90 seconds. When it is finished, the
- LED indicator will flash BLUE 3 times then will turn off.

  When **Deep Sanitize** mode is activated, the LED indicator on the lid of the sanitizer will **turn GREEN**, and the sanitizer will sterilize for the next  ${\bf 5}$  minutes. When it is finished, the LED indicator will flash GREEN 3 times then will turn off.



90 Seconds Fast Sanitize



5 minutes (300s)

Once the UV sanitizer is completely finished sanitizing, open the lid, flip your device over, and repeat the sanitization again for other side of your device.

Caution: This device is designed to limit human & animal exposure to UV-C light, as it is harmful to skin and eyes. This device is equipped with a safety feature that automatically shuts the UV-C light OFF when the lid is opened.