

MILEX™ LED SHOWER HEAD INSTRUCTIONS



Shower Head hose connection is used in most hoses, and meets international standards



1. Place the hose gland on the hose connector to prevent water leakage.



2. Tighten the showerhead



3. Install on the base of the normal water line

DISCLAIMER NOTICES

In the process of the preparation of this manual, we have sought to make the content correct and complete. However, there is no guarantee that there are no errors or omissions in the manual.

We reserve the right to change specifications of the products mentioned in this manual at any time without prior declaration. No part of this manual shall be reproduced, transmitted, transcribed or stored in a searchable system or translated into any other languages without the written authorization of our company. The company is not responsible for the loss caused by non-standard or wrong operation.

WARRANTY CLAUSES

Damage caused by failure to follow the instructions, human factors, force majeure, etc. is not covered by warranty. Maintenance cost will be charged for product out of warranty. You can register for your free warranty on www.IGIA.com.

Customer Service Phone: 516-653-0666

Email: Sales.IgiaNY@gmail.com.

Individual results may vary. This product has not been evaluated by the FDA.

The product color or appearance may vary.

WWW.IGIA.COM

**SCAN FOR MORE
PRODUCTS**

